

Drawing Reference Numbers

<u>DRG.</u> <u>REF</u>	<u>DESCRIPTION</u>	<u>DRG.</u> <u>REF</u>	<u>DESCRIPTION</u>
01A	BODY	P101	BEARING
06A	NAMEPLATE (SOG)	P102	BEARING
06B	NAMEPLATE (DOG)	P103	LIP SEAL
10A	LIPSEALS	P105	HEX. HD. BOLT
11A	BEARING COVER	P106	HEX. NUT
15A	THROWER GUARD	P107	WASHER
20B	GASKET (SUCTION CHAMBER)	P108	SPRING WASHER
22A	STATOR	P109	THRD. CUT SCREW
23A	SUCTION CHAMBER	P110	WASHER
24A	END COVER	P111	SOC. HD CAP SCREW
25A	ROTOR/FLEXISHAFT ASSY	P112	SPRING WASHER
32A	SHAFT	P113	DRIVESCREW
35A	BEARING SPACER	P401	SQ PAR KEY
47A	HALF RING	P402	SEAL
47B	HALF RING	P404	SOC. CAP SCREW
62A	SUPPORT FOOT	P408	LOCKNUT
62B	SUPPORT FOOT	P409	LOCKWASHER
65A	GLAND SECTION	P416	SPRING WASHER
76A	ADAPTOR FLANGE – HALF RINGS	P502	TAPER PLUG
76B	ADAPTOR FLANGE – HALF RINGS	P503	HEX NUT
		P504	SPRING WASHER
		P505	WASHER
		P506	HEX NUT
		P507	SPRING WASHER
		P508	WASHER
		P527	HEX HD BOLT
		P528	SPRING WASHER
		P529	WASHER
		P530	HEX NUT
		P580	HEX HD BOLT
		P581	STUD
		P582	STUD

IMPORTANT NOTE

THE DRAWING REFERENCES SHOWN GIVE THE DESCRIPTION OF ALL THE PARTS DETAILED ON THE SECTIONAL DRAWINGS IN THIS SECTION OF THE BOOK. THEREFORE SOME OF THE REFERENCES MAY NOT BE SHOWN ON ANY ONE.

